


TimeIt

Weekly Digital Timer

3-Wire Grounded Outlet and Plug
Rated: 120VAC, 60Hz, 10A, 1200W Resistive Load,
Customer Service: 1.800.730.3707

READ ALL INSTRUCTIONS - IMPORTANT!

Before using the timer plug it in for 10 - 15 minutes; then press the reset button



SET CURRENT TIME:

- ① Press and hold the “**TIME**” button, then press the “**WEEK**” button to set the current day.
- ② Press and hold the “**TIME**” button, then press the “**HOUR**” button to set the current hour.
- ③ Press and hold the “**TIME**” button, then press the “**MIN**” button to set the current minute.

SET PROGRAM:

- ① Press the “**PROG**” button to enter the program setting; you will see all the days of the week on the top and “**1 ON**” to the left of the display.
- ② Press the “**WEEK**” button to set the program “**1 ON**” days of the week that you want the timer to function.
- ③ Press the “**HOUR**” button to set the program “**1 ON**” hour.
- ④ Press the “**MIN**” button to set the program “**1 ON**” minute.
- ⑤ Press the “**PROG**” button once and repeat step 2 to 4 to set program “**1 OFF**”.
- ⑥ After setting the program “**1 OFF**” press the “**TIME**” button once to return to the current time.

You can set up to 8 different ON and OFF times for your timer. To do so, just repeat step 2 to 5 for program “**2 ON**”, “**2 OFF**”, “**3 ON**” etc...

MANUAL OVERRIDE:

Pressing the “**ON/OFF AUTO**” button when the current time is being displayed will allow you to set the status of the timer:

- If “**ON**” is to the left side of the display, the timer will be active until the “**ON/OFF AUTO**” button is pressed.
- If “**OFF**” is to the left side of the display, the timer will not activate until the “**ON/OFF AUTO**” button is pressed.
- If “**AUTO**” is to the left side of the display, the timer will run on the program setting until the “**ON/OFF AUTO**” button is pressed.

SET VACATION SECURITY:

Pressing the “**TIME**” and “**PROG**” buttons simultaneously will activate security mode. If “**SEC**” is to the right side of the display the timer will turn on randomly during different parts of the day. Simply press “**TIME**” and “**PROG**” simultaneously to disable “**SEC**”.

NOTES:

- ① The unit you are plugging into the timer has to be on.
- ② Make sure AM and PM are correct on the current time and in the program settings.

SAVE THESE INSTRUCTIONS!